



Uniden TCX905 Battery Pack Replacement

This guide will show the user how to remove the battery pack.

Written By: Gary Pence



INTRODUCTION

The battery is what charges the phone, and the phone will not operate without it. This must be removed in order to access the inside of the phone.

Step 1 — Battery Cover



- Starting from the top of the cover, slide down and away from the phone with your thumb
- Lift battery cover off of batter and place it to the side

Step 2 — Battery Pack



- Once battery cover is removed, place your thumb and index fingers on the the wires near the receptacle
- Gently pull straight up on the wires until a click is heard which signifies the battery is completely disconnected
- Place battery pack to the side

To reassemble your device, follow these instructions in reverse order.