

NETVANTA 6310

P/N 1702100G1

GETTING STARTED

Two configuration methods are available for your NetVanta 6310 unit:

- Web-based graphical user interface (GUI)
- Command line interface (CLI)

The GUI lets you configure the main unit settings and provides online guidance and explanations for each setting. However, using the AOS CLI may be necessary for more advanced configurations.

ACCESS THE GUI

You can access the GUI from any web browser on your network by following these steps:

1. Connect the unit to your PC, using an Ethernet cable connected to **ETH 0/1** port on the back of the unit.
2. Set your PC to obtain an IP address automatically using Dynamic Host Configuration Protocol (DHCP), or change your PC to a fixed IP address of **10.10.10.2**. To change your PC's IP address, or to set the PC to use DHCP, navigate to **Computer > Control Panel > Network Connections > Local Area Connection > Properties > IP (TCP/IP)** and select either **Use this IP address** or **Obtain an IP address automatically** (this means you are using DHCP). If you are specifying an IP address, enter these parameters:

IP Address: **10.10.10.2**
Subnet Mask: **255.255.255.0**
Default Gateway: **10.10.10.1**

You do not need to enter any domain naming system (DNS) server information. After the information is entered, select **Ok** twice, and close the Network Connections dialog box. If you cannot change the PC's IP address, you will need to change the unit's IP address using the CLI. (Refer to the next two sections for instructions.)

3. Enter the unit's IP address in your browser's address line. The default IP address is **10.10.10.1**, but if you changed the unit's IP address enter that address in the browser line.
4. You will then be prompted for the user name and password (the default settings are **admin** and **password**).
5. The initial GUI menu appears. You can access initial setup information by selecting **Config Wizard** from the menu on the left.



*It is best to only use the **Config Wizard** for new installations because some existing settings can be lost or reset when using this wizard.*

Access the AOS CLI using the **CONSOLE** port or a Telnet session. To establish a connection to the unit's **CONSOLE** port, you need the following items:

- PC with VT100 terminal emulation software
- Straight-through serial cable with a DB-9 (male) connector on one end and the appropriate interface for your terminal or PC communication port on the other end



*You can find VT100 terminal emulation software on most PCs by navigating to **Start > Programs > Accessories > HyperTerminal > HyperTerminal**. When you have opened a HyperTerminal session, enter the settings described in Step 4.*

1. Connect the DB-9 (male) connector of your serial cable to the **CONSOLE** port on the rear panel of the unit.
2. Connect the other end of the serial cable to the terminal or PC.

**NOTE**

Many PCs do not come with a standard serial port. A universal serial bus (USB) to serial adapter can be used instead. The drivers for the USB to serial adapter must be installed according to the manufacturer's instructions. If the USB to serial adapter is not properly installed on your PC, you will not be able to communicate with the AOS unit and you should seek support from the USB to serial adapter manufacturer.

3. Insert the connector of the provided power cord into the power interface on the rear panel of the unit, and plug the cord into a standard electrical outlet. Refer to the [NetVanta 6310/6330 Series Hardware Installation Guide](#) at <https://supportforums.adtran.com> for more details.
4. Once the unit is powered up, open a VT100 terminal session using the following settings: 9600 baud, 8 data bits, no parity bits, and 1 stop bit. Press **<Enter>** to activate the AOS CLI.
5. Enter **enable** at the **>** prompt. Enter the enable password when prompted. The default password is **password**.

You can also access the CLI from a Telnet client. In order to do this, you must know the IP address of the AOS device. If you do not know the unit's IP address, you must use the **CRAFT** port to access the CLI. To access the CLI using a Telnet client, follow these steps:

1. Connect the unit to your PC, using an Ethernet cable connected to **ETH 0/1** port on the back of the unit.
2. Open a Telnet client on your computer. You can access the Telnet client by navigating to **Start > Run** and entering **telnet 10.10.10.1** (Windows® XP). If you are running Windows Vista, you will need to turn on the Telnet client before you access it. To do this, navigate to **Start > Control Panel > Programs and Features > Turn Windows features on or off > Telnet Client Option** and select **OK**. **10.10.10.1** is the default unit IP address. If you have changed your unit's IP address, you will need to enter that address.
3. Enter **enable** at the **>** prompt and enter the enable password when prompted. The default password is **password**.

COMMON CLI COMMANDS

The following are common CLI commands and tips for getting started with the CLI.

- Entering a question mark (?) shows contextual help and options. For example, entering ? at the prompt will show all commands available from that prompt.
- To view interface statistics, enter **show interface <interface type> <interface number>**.
- To view the current configuration, enter **show running-config**.
- To view all the IP addresses currently configured, enter **show ip interface brief**.
- To view the AOS version, serial number, and other information, enter **show version**.
- To save the current configuration, enter **write**.

CONFIGURE THE UNIT'S IP ADDRESS

**NOTE**

*The configuration parameters used in the examples outlined in this document are for instructional purposes only. Replace all underlined entries (**example**) with your specific parameters to configure your application.*

The following steps create an IP address and subnet mask for **ETH 0/1**.

1. At the **#** prompt, enter **config terminal**.
2. At the **(config)#** prompt, enter **interface eth 0/1** to access the configuration parameters for the Ethernet port located on the rear of the unit.
3. Enter **ip address 10.10.10.1 255.255.255.0** to assign an IP address to the Ethernet port using a 24-bit subnet mask.

4. Enter **no shutdown** to activate the interface to pass data.
5. Enter **exit** to exit the Ethernet interface commands and return to the Global Configuration mode.
6. Enter **ip route 0.0.0.0 0.0.0.0 192.168.1.254** to add a default route to the route table. **0.0.0.0** is the default route and the default subnet mask, and **192.168.1.254** is the next-hop IP address to which the AOS unit should send all of its traffic. You will need to enter the proper route, subnet mask, and gateway for your network. This information is typically provided by an Internet service provider (ISP) or local network administrator.
7. Enter **do write memory** to save the current configuration.

ENABLE TELNET USER LOGIN ACCESS

The following steps create a password of **adtran** for Telnet access. By default, Telnet access is enabled with a password of **password**.

1. Verify that the prompt of your unit displays **(config)#**.
2. Enter **line telnet 0 4** to change the configuration parameters for the Telnet sessions.
3. Enter **login** to initiate Telnet access.
4. Enter **password adtran** to change the login password for the Telnet sessions.
5. Enter **exit** to return to the Global Configuration mode.
6. Verify that the prompt of your unit displays **(config)#**.
7. Enter **do write memory** to save the current configuration.

CONFIGURE YOUR APPLICATION

The applications you will need to configure vary by product and by network. Review the list of defaults for your unit before deciding what applications to configure. The following are some common applications that should be configured on startup. These are all available on [ADTRAN's Support Community](#).

Configuring T1 Access to a Remote Site Using PPP in AOS (video article 2003)	Configuring Internet Access (Many to One NAT) with the Firewall Wizard in AOS (video article 2185)
Configuring Port Forwarding in AOS (video article 2291)	Configuring QoS for VoIP in AOS (video article 3091)
Configuring PPP in AOS (article 2523)	Configuring HDLC in AOS (article 2152)
Configuring Frame Relay in AOS (article 2350)	Configuring QoS in AOS (article 1617)
Configuring DHCP Server in AOS (article 2149)	Configuring a VPN Using Main Mode in AOS (article 1925)
Configuring a VPN Using Aggressive Mode in AOS (article 1926)	Configuring Voice Traffic over SIP Trunks in AOS (article 3395)
Configuring the Switchboard and Dial Plan in AOS (article 2130)	Configuring PRI Signaling for DSX-1 in AOS (article 3396)
Configuring Enhanced ANI/DNIS Substitution in AOS (article 2509)	Configuring Source and ANI Based Routing in AOS (article 2510)



Important: For additional details on product features, specifications, installation, and safety, refer to *NetVanta 6310 Hardware Installation Guide* at <https://supportforums.adtran.com>.

NETVANTA 6310 DEFAULTS

Feature	Default Value
IP Address	10.10.10.1
User Name	admin
Password	password
HTTP Server	Enabled
Event History	On
IP Routing	Enabled

RESTORING FACTORY DEFAULTS

On units that have a console port, you cannot restore the factory defaults, but must rather erase the device's configuration and then reconfigure the unit to operate correctly for your network. To erase the unit's current configuration, follow these steps:

1. Access the unit's CLI and enter **enable** at the > prompt.
2. Enter **erase startup-config** at the # prompt. The device will have a blank configuration upon reboot.
3. Enter **reload** at the # prompt to begin restarting the device. When prompted to save configuration, enter **no**. When prompted to reboot, enter **yes**.
4. Upon reboot, you will have to reconfigure the unit using the **CRAFT** port. Follow the steps outlined here or in the technical note, [Accessing the Web Interface in AOS](https://supportforums.adtran.com) available at <https://supportforums.adtran.com>.