

Licensing, Capacity Usage Threshold Reached, Major

Ericsson Centralized User Database

OPERATING INSTRUCTION

Copyright

© Ericsson AB 2016-2018. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

| | | |
|----------|-----------------------|----------|
| 1 | Introduction | 1 |
| 1.1 | Alarm Description | 1 |
| 1.2 | Prerequisites | 3 |
| 2 | Procedure | 5 |
| | Glossary | 7 |
| | Reference List | 9 |



Licensing, Capacity Usage Threshold Reached, Major



1 Introduction

This instruction concerns alarm handling for the Licensing, Capacity Usage Threshold Reached, Major alarm.

1.1 Alarm Description

This alarm is raised when the reserved capacity limit in a capacity license has been reached.

The alarm is issued in the following situations:

- The capacity usage limit has been reached for the Payload Blades / Virtual Machines.
- The capacity usage limit has been reached for the active HLR Profile.
- The capacity usage limit has been reached for the active HSS-IMS Profile.
- The capacity usage limit has been reached for the active HSS-EPC Profile.
- The capacity usage limit has been reached for the active AUC Profile.
- The capacity usage limit has been reached for the Small Generic Profile.
- The capacity usage limit has been reached for the Medium Generic Profile.
- The capacity usage limit has been reached for the Large Generic Profile.
- The capacity usage limit has been reached for the active IoT Profile.
- The capacity usage limit has been reached for the active HSS-EPC 5G Profile.

The possible alarm causes and the corresponding fault reasons, fault locations, and impacts are described in Table 1.

Table 1 Alarm Causes

| Alarm Cause | Description | Fault Reason | Fault Location | Impact |
|--|--|---|-----------------|---|
| The licence capacity limit of the capacity profile license has been reached. | The capacity usage limit has been reached. | The requested capacity has reached the total licensed capacity defined in the capacity profile license. | License Manager | Violation of license agreements. |
| The license capacity limit of the Payload Blades / Virtual Machines capacity license has been reached. | The capacity usage limit has been reached. | The requested capacity has reached the total licensed capacity defined in the Payload Blades / Virtual Machines capacity license. | License Manager | Additional capacity exceeding the usage limit is unavailable. |



The alarm attributes are listed and explained in Table 2.

Table 2 Alarm Attributes

| Attribute Name | Attribute Value |
|------------------------------|--|
| Auto Cease | Yes |
| Module | LICENSING |
| Error Code | 6 |
| Timestamp First | Date and time when the alarm was raised for the first time. |
| Repeated Counter | Number which indicates how many times the alarm was raised. |
| Timestamp Last | Date and time of the most recent alarm raised. |
| Resource ID | 1.3.6.1.4.1.193.169.14.2.3.<# SUB_LICENSE_SUFFIX> |
| Alarm Model Description | License Management, Licensing |
| Alarm Active Description | Capacity Usage Threshold Reached for <#LICENSE_TYPE>, Major |
| ITU Alarm Event Type | qualityOfServiceAlarm (3) |
| ITU Alarm Probable Cause | thresholdCrossed (549) |
| ITU Alarm Perceived Severity | (4) – Major |
| Originating source IP | Node IP where the alarm was raised. |
| Sequence Number | Number which indicates the order in which the alarms are raised. |

The available values of the <#SUB_LICENSE_SUFFIX> and <#LICENSE_TYPE> variables shown in Table 2 are listed below. The list follows the below format: "<#SUB_LICENSE_SUFFIX>" for the <#LICENSE_TYPE>.

- “1” for the Payload Blades / VMs.
- “2” for the HLR Profile.
- “3” for the HSS-IMS Profile.
- “4” for the HSS-EPC Profile.
- “5” for the AUC Profile.
- “6” for the Small Generic Profile.
- “7” for the Medium Generic Profile.
- “8” for the Large Generic Profile.
- “9” for the IoT Profile.
- “10” for the HSS-EPC 5G Profile.

For further information about attribute descriptions, refer to the Alarm Format and Description section of CUDB Node Fault Management Configuration Guide, Reference [1].



1.2 Prerequisites

This section provides information on the documents, tools, and conditions that apply to the procedure.

1.2.1 Documents

Before starting this procedure, ensure that you have read the following documents:

- CUDB Node Fault Management Configuration Guide, Reference [1]
- System Safety Information, Reference [3]
- Personal Health and Safety Information, Reference [4]

1.2.2 Tools

Not applicable.

1.2.3 Conditions

Not applicable.



Licensing, Capacity Usage Threshold Reached, Major



2 Procedure

If the alarm is raised, then refer to the [License Management, Capacity Usage Threshold Reached, Reference \[5\]](#) document for the procedure to perform.

Note: Perform only the actions that are applicable for LM deployments using ELIM license key files. The applicable severity is “Major”.



Licensing, Capacity Usage Threshold Reached, Major



Glossary

For the terms, definitions, acronyms and abbreviations used in this document, refer to [CUDB Glossary of Terms and Acronyms, Reference \[2\]](#).



Licensing, Capacity Usage Threshold Reached, Major



Reference List

CUDB Documents

- [1] CUDB Node Fault Management Configuration Guide
- [2] CUDB Glossary of Terms and Acronyms

Other Ericsson Documents

- [3] System Safety Information
- [4] Personal Health and Safety Information
- [5] License Management, Capacity Usage Threshold Reached