



1 What's in the box?



DSM-330



A/V Composite cable



SCART to component cable



HDMI Cable



CAT-5 Ethernet Cable




CD




Power cord with
AC adapter



Wireless Antenna



Remote Control



Quick Setup Guide



2 AAA batteries
(for remote control)

2 Install the DivX Connected software

Software Installation

Place the installation CD in the PC's optical drive. If the setup program does not launch automatically, Click Start, click Run, type Drive:\Launch in the Open box, and then click OK, where Drive is the letter drive of your CD-ROM

General Requirements:

- Windows® XP Pro/Home or Vista editions
- 60 MB HDD space
- CD-ROM capable drive
- Graphics driver update may be required

Recommended (for High Definition TV):

- 2.6 GHz Pentium 4 or Athlon PC
- 1 GB system RAM
- Hardware accelerated OpenGL enabled video card
- Wired or Wireless 802.11g network

Minimum (for Standard Definition TV):

- 1.6 GHz Pentium 4 or Athlon PC
- 512 MB system RAM
- OpenGL enabled video card
- Wired or wireless network




DivX Connected™

3 Connect the DivX Connected device to your network

The DSM-330 gives you two options to connect to your network:

Wired: Connect the DSM-330 directly to your router (recommended for HD video)

Wireless: Connect the DSM-330 to your existing wireless router wirelessly.



Continued


Connect the DivX Connected device to your network (continued)

Note: This guide assumes that you already have a PC connected to your home network. If you are installing a network for the first time, please follow the network installation instructions for your router first.


Wired Connection: Refer to Steps 1 and 2 only

Wireless Connection: Refer to Steps 1 and 3 only

1. Attach the wireless antenna to the back of the device, as shown in the diagram on bottom left.
2. For wired Ethernet, connect a Cat-5 cable between the device and router, as shown in the diagram on bottom right.
3. For wireless connection, ensure the antenna is attached and have your network name (or SSID) and your encryption key (if needed) available. This information will be required after completing Step 6 of the installation.



Attach the wireless antenna to your DivX Connected device





4 Connect the DivX Connected device to your TV

GOOD

Standard Definition TV connection

Using the A/V composite cable, connect the DivX Connected device to your TV.

DivX Connected device TV




- or -

BETTER


SCART Component TV connection

Using the SCART component cable, connect the DivX Connected device to your TV. Using audio connection cables, connect the audio on the DivX Connected device to the audio on your TV.

DivX Connected device



TV




- or -

BEST


HDMI TV connection

Using the HDMI cable, connect the DivX Connected device to your TV.
If your TV doesn't receive audio through the HDMI cable, connect the audio cables.

DivX Connected device



TV




For other connections not shown here, please refer to the DivX Connected user Guide.

5 Power on the DivX Connected device

DivX Connected device



- A** Connect the power cord to the device and power source
- B** Turn on the TV
- C** Turn on the device by pressing the power button 


If you don't see the language selection screen, make sure your TV is set to display the correct video input. The method for changing the TV input depends on the model, but your TV may have an "Input" or "A/V" button on the TV or on the remote control to select various inputs.

6 Configure the DivX Connected device



Follow the on-screen instructions for configuring the DivX Connected device. First select your language from the list using the **Up** or **Down** arrow keys on the remote control. Use the **Right** arrow key to advance to the next setup screen until all required items are configured. To return to a previous screen, press the **Left** arrow key.

7 Using the remote control



- Press the Arrow buttons to move around the page or to go to the next (**Right**) or previous (**Left**) screen
- Press the **Enter** button to select an item
- Press the **Back** button to go back to the previous screen
- Press the **Menu** button to display additional options on a screen
- Press the **Setup** button to configure the device
- The **Arrow** and **Enter** buttons also control trick modes during video playback
- Review the **Navigating in Connected** section of the user guide for more information about navigating each type of media

8 Troubleshooting

No power

Check that the AC power cord is plugged into both the power receptacle and the AC adapter. Check that the power jack is plugged securely into the back of the device.

Check the connections to the TV and make sure all plugs are firmly in place.

No picture

Check your TV manual to determine how to get the video input you've connected to the DivX Connected device to display on the TV.

No sound or distorted volume

Adjust the volume on the TV or device. Check that the audio connections are going to the correct input source on the TV. TV's with more than one video input usually have separate audio inputs as well.

Remote control does not work

Make sure existing batteries are properly installed or try new batteries.

Move closer to the DivX Connected device and point the remote directly at its front panel.

If this doesn't help, please visit us online at <http://support.dlink.ca>



Questions? For Connected community information, visit us online at <http://labs.divx.com/connected>

© 2007. All rights reserved. DivX, Inc.

DivX®, DivX Connected™ and associated logos are trademarks of DivX, Inc.

The information contained in this document is subject to change without notice.

6ESM330Q..02G