

DBS, NR, Unknown Object Type

OPERATIONAL INSTRUCTIONS

Copyright

© Ericsson AB 2016–2018. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks are properties of their respective owners.



Contents

1	Alarm Description	1
2	Procedure	2
2.1	Handle Alarm DBS, NR, Unknown Object Type	2



DBS, NR, Unknown Object Type



1 Alarm Description

The alarm is raised when one or more Persistent Object Types (POTs) configured to be shared between the clusters are unknown to the database.

Table 1 DBS, NR, Unknown Object Type Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
Unknown netshared POTs configured	One or more POTs configured to be shared between clusters are unknown to the database.	N/A	Configuration	The unknown POT is not synchronized with the peer cluster. Initial synchronization is not possible with a peer knowing these POTs.

Note: The alarm can appear as part of a software upgrade procedure, as the POTs introduced by new software can temporarily be unknown to the database.

Table 2 Alarm Attributes

Attribute Name	Attribute Value/Interpretation
Major Type	193
Minor Type	918534
MO Class	DbService
Source	DbsvDirector
Specific Problem	DBS, NR, Unknown Object Type
Event Type	COMMUNICATIONSALARM
Probable Cause	frequencyHoppingFailure (74)
Perceived Severity	MAJOR
Additional Information	A list of the unknown POT RTIDs



2 Procedure

2.1 Handle Alarm DBS, NR, Unknown Object Type

Prerequisites

- No documents are required.
- No tools are required.
- Before starting this procedure, ensure that the following condition is met:
 - The alarm is raised.

Steps

1. Is the alarm raised during a software upgrade?

Yes: Wait until the software upgrade is finished. Continue with the next step.

No: Proceed with Step 3.
2. Is the alarm cleared?

Yes: Proceed with Step 4.

No: Continue with the next step.
3. Is the alarm raised after a software upgrade?

Yes: Contact the provider of the upgraded software package because the upgraded configuration does not match the contained software.

No: Contact the next level of maintenance support. Further actions are outside the scope of this Operating Instruction.
4. Job is completed.