




Asus VivoBook X540SA-BPD0602V Battery Removal

In this guide you will learn how to safely remove the battery from the laptop case.

Written By: Jessica Browne



INTRODUCTION

In this guide you will learn how to replace your Asus Vivobook X540SA-BPD0602V battery. Batteries should be replaced every couple of years because over time, they will fail to hold a charge. All power sources, including the battery, should be removed before completing any repairs or replacements within the device.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Keyboard



- Power down the laptop using the device's power button in top right corner of the keyboard. Ensure that the device's power cord is disconnected.

Step 2



- Flip the laptop over so the back panel is displayed.

Step 3



- Using a Phillips #0 screwdriver, remove the ten screws from the back panel.
- Remove the two battery screws (15.6 mm)
- Two top corner screws (12.5 mm)
- Six case screws (9.7mm)

Step 4




- Flip the laptop back over and open it, revealing the screen and keyboard.

Step 5




- Use the plastic opening tool to wedge and loosen the seal all the way around the edges. Carefully lift up the keyboard panel.
- ⚠ When lifting the keyboard panel, do not lift it all the way as the two connection ribbons to the motherboard must be disconnected.
- ⓘ It is recommended to break the seal of the case starting at the upper corners closest to the hinge.

Step 6



- Observe where the ribbons connect to the motherboard; there are two connections. Each connection has a black clamp. To remove the ribbon, lift up the black clamp and disconnect.

Step 7 — Battery



- Very carefully, remove the batteries with the same blue plastic iFixit opening tool used in the first tutorial.

Focus your efforts on the combed hinge to the left of the batteries.

-  The batteries should all be connected to one another and come out of the device as a single unit.
-  Be careful not to rip any of the black plastic covering the batteries. Exposed battery parts can lead to explosions. If the case is ripped, re-wrap them, or properly dispose of them. Do not use them.

To reassemble your device, follow these instructions in reverse order.